


For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
 (BLACK) (WHITE) (BISCUIT) (STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


# OVEN PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT4455988	Installation Instructions
	LIT8300890	Use & Care Guide
	LIT4450786	Cook Guide Label
	LIT4451052	Guide—Easy Use M/W
	LIT8302335	Tech Sheet
	LIT4449264	Easy Set Guide
	LIT3191638	Safer Cooking Tips
2		Trim, Side
	4452624	RH Black
	4452626	RH White
	4452971	RH Biscuit
	4452556	RH Stainless
	4452625	LH Black
	4452627	LH White
	4452972	LH Biscuit
	4452557	LH Stainless
3	4451605	Cap, Spacer
4		Rail, Side
	4456545	Right Side
	4456546	Left Side
5	4452559	Side, Chassis (R.H. & L.H.)
		Screw
	694091	S. Steel
	8281236	Black
6	4456400	Base, Chassis
7		Trim, Bottom
	4456539	Black
	4456541	White
	4456543	Biscuit
	4456537	Stainless
8	4452553	Chassis, Back
9	4455471	Spacer
10	3400832	Screw
11	4449809	Screw
12	4452492	Insulation—Grill
13	4452491	Insulation—Top

# CONTROL PANEL PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)




Illus. No.	Part No.	DESCRIPTION
1	4452602	Panel, Control Black
	4452603	White
	4452973	Biscuit
	4451790	Stainless
2	4453421	Switch, Membrane Black
	4453422	White
	4453425	Biscuit
	4453419	Stainless
3	4452248	Insulator, Board
4	4452249	Insulator, Board Support
6	4452345	Insulator, Dielectric
7	8302345	Assy, Control
8	3400406	Screw
9	3400832	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MICROWAVE COMPARTMENT PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
5	4456399	Support Rails
11	4452547	Rear Channel
12	4449809	Screw
13	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS


For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03

(BLACK)

(WHITE)

(BISCUIT)

(STAINLESS)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET AND STIRRER PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03

(BLACK)

(WHITE)

(BISCUIT)


(STAINLESS)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	27	4375321	Fuse	52	4375427	Thermoactuator
3	4375252	Rubber Ring	28	4375231	Block, Fuse	53	4375426	Air Bleed
4	4375038	Screw	29	4375278	Motor, Blower	54	4375439	Shield, Heat Right
5	4375314	Air Duct, Magnetron	30	4375279	Thermostat	55	4375422	Sensor, Temp.
6	4375253	Support, Tube	31	4375423	Thermostat	56	4375420	Insulation
7	4375421	Plug, Ceramic	32	4375281	Thermostat	57	4375419	Duct, Heater
8	4375255	Bushing	33	4375408	Q Tube Assembly	58	4375416	Washer
9	4375256	Reflector	34	4375438	Transformer	59	4375417	Element, Heater
10	4375257	Chamber, Reflector	35	4375406	Ring, Turntable	60	4375418	Fan
12	4375450	Duct, Inlet	36	4375407	Shaft, Turntable	61	4375429	Motor, Fan
13	4375316	Insulation, Switch	39		Bracket, Hinge	62		Left-Threaded Nut Serviced With Motor Item 61
14	4375322	Fan Wheel		4375412	Left	63	4375430	Thermostat
15	4375317	Duct, Air		4375413	Right	64	4375431	Shield, Heat
16	4375415	Block, Slide	42	4375331	Plate, Grill	65	4375432	Insulation
17	4375248	Cover Plate, Upper	43	4375332	Bracket	66	4375433	Chamber, Heat
18	4375251	Screw	44	4375441	Fan Cap	67	4375437	Isolation Plate
19	4375318	Lens, Lamp	46		Switch Holder	68	4375338	Cover Plate
20	4375319	Spring		4375412	Left	71		Side Plate
21	4375320	Reflector		4375413	Right		4375341	Left
22	4393900	Pan Handle	47	4375258	Nut		4375342	Right
23	4452220	Rack	48		Insulation	72	4375405	Turntable
24	4393536	Crisp Plate		4375409	Left Side	73	4375346	Switch
25	4375436	Capacitor		4375410	Right Side	74	4375347	Motor, Turntable
26	4375424	Magnetron	49	4375411	Plate, Side Bottom	75	4375348	Lamp
			50	4375425	Valve	76	4375349	Rectifier
			51	4375428	Screw To Valve	77	4375435	Cable

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	4450377	Cover, Top
2	4448935	Baffle, Blower
3	4450920	Blower
4	4451789	Plate, Mounting
5	6610122	Transformer, (Lights)
6	4450366	Exhaust Duct
7	4450027	Bracket, Duct


Illus. No.	Part No.	DESCRIPTION
8	4449964	Grommet
11	4449868	Block, Terminal
13	4456144	Vent-Cntrl Panel
14	4451597	Side, Control Top
	4451598	Right
	4451598	Left
15	4452244	Back, Control
16	4450550	Cover, Top Rear
17	4448664	Clamp
18	4452366	Cover, Top Front

Illus. No.	Part No.	DESCRIPTION
19	4455038	Transformer-Cntrl Control
20	4452247	Cover, Plate
21	4449809	Screw
22	3400016	Screw
23	112432	Nut
24	1180485	Screw
25	4451934	Suppressor
26	3400016	Screw
27	4450118	Nut

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MICROWAVE DOOR PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)



Illus. No.	Part No.	DESCRIPTION
1	4448937	Glass, Middle
2	4450945	Frame, Door
4	4449141	Bracket, Mounting
	4449142	Right Side
	4449142	Left Side
5	4449083	Filler, Side
	4449086	Right Side
	4449086	Left Side
6	4452500	Handle, Door
	4452500	Black
	4452501	White
	4452870	Biscuit
	4452087	Stainless

Illus. No.	Part No.	DESCRIPTION
7	4452210	Glass, Outer
	4452210	Black
	4452788	White
	4452994	Biscuit
	4452258	Stainless
8	4451055	Spacer (Stainless)
9	4452330	Bracket, Handle
10	4450863	Retainer, Glass-Clip
	4450863	Black
	4450864	White
	4452119	Biscuit
	4451432	Stainless
11	4375339	Door, Plate

Illus. No.	Part No.	DESCRIPTION
12	4375414	Frame, Inner
13	4375330	Strap, Door
14	4375313	Screw
15	4375323	Hinge, Door
	4375323	Left
	4375324	Right
16	4451008	Spring, Torsion
	4452398	BI/Wh/Bt Model
	4452398	Stainless Model
18	4449809	Screw
19	4449040	Screw
20	4450038	Screw
21	4451040	Screw
	3196184	BI/Wh/Bt Model
	3196184	Stainless Model

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: KBMC147HBL03, KBMC147HWH03, KBMC147HBT03, KBMC147HSS03  
(BLACK) (WHITE) (BISCUIT) (STAINLESS)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

72017	White
261869	Cord Brown
72032	Black

## PAINT, SPRAY

350930	White
261900	Citrine White
830864	Black

## FOLLOWING PARTS NOT ILLUSTRATED

482338	Sealer, Silastic (3 oz.)
--------	-----------------------------

## WIRING HARNESS PARTS

4453215	Harness, Main
4450831	Wire, Ground
4450800	Screw, Ground
4450950	Conduit, Combo
4448950	Screw, Install (4)
4452400	Lead, Ground Strap

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST